



INSTALLATION INSTRUCTIONS

1. Cut off pipe to 1" or less above roof line.
2. Caulk and seal around pipe.
3. Put generous bead of caulk around the bottom flat area of vent.
4. Press vent in place over pipe opening.
5. Fasten vent with 12 screws, starting on each side of rib in the middle.
*****USE TEMPLATE FOR SCREW PLACEMENT*****
6. Smooth out excess or add caulk around vent to insure a watertight seal.

